

# EDEN by DEVOX

Explore endless possibilities with  
DEVOX's new decking range.

Crafted for those who seek both luxury and longevity in outdoor living, our decking solution combines exquisite design with unmatched resilience.

Step into a world of elevated outdoor living with our brand new WPC, EDEN by DEVOX, decking.

Easy Installation and maintenance  
No Oiling.  
No Sealing.  
No Fading.



DEVOX

# AVAILABLE COLOUR RANGE

WALNUT



IPE



MAGIC GREY



DARK GREY



ANTIQUE



OAK




TEAK



MAPLE



## DIMENSIONS & TECHNICAL SPECS



### NCC Compliant Testing for Slip Rating

Australian Standard	TEAK	IPE
AS4586(A) Wet Pendulum Test	P1	P1
AS4586(B) Dry Floor Friction Test	D1	D0
AS4586(C) Wet Barefoot Inclining Platform Test	B	B

## APPLICATIONS

Patios and Rooftops

Pool side Decks

Backyard Decks

Garden Pathways

Boardwalks

DIY Projects

## ACCESSORIES

Starter Clip




Middle clip



Anti-slip Clip



#8-18 x 5/8" CSK Square Self Tapper Screws Zinc Black





Board colour: Oak

# INSTALLATION GUIDE


## BEFORE YOU BEGIN

**INSPECT PANELS:** Ensure that all EDEN panels are in good condition before installation.

## REQUIRED TOOLS AND MATERIALS



Impact drill



Measuring tape



Circular saw



Spirit level


### STEP 1: PRE-REQUISITES



A. Inspect all EDEN by DEVOX decking panels for defects or damage



B. Measure the decking area accurately to determine the required number of panels.



C. Plan the layout, taking into account any design features or cutouts.



D. Construct a sturdy wooden frame or post to support the decking structure. Ensure the frame is level using the spirit level.



E. Prepare for any necessary cuts for corners or edges using a circular saw.


### STEP 2: INSTALLING THE STARTER BOARD



A. Determine the appropriate spacing and position for the Starter Clips (C-clips) along the frame.



B. Screw the Starter Clips (C-clips) securely to the frame at the designated locations.



C. Place the starter board onto the C-clips, ensuring it is aligned and level.



D. Install at least one anti-slip clip per length of the starter board.



E. Make sure the starter board is level using the spirit level.

### STEP 3: INSTALLING THE EDEN BY DEVOX PANELS



A. Position middle clips at regular intervals along the starter board and screw them in place.



B. Place the EDEN by DEVOX decking panel onto the middle clips. The clips will automatically provide the appropriate gap between panels.



C. Secure the panels in place, ensuring they are aligned and level.



D. Install at least one anti-slip clip per length of the panel.



E. Check the alignment and levelness of each panel using the spirit level.

### SAFETY PRECAUTIONS:



Always wear appropriate safety gear, including goggles and gloves, when handling tools and materials. Use caution when operating power tools, and follow manufacturer instructions for safe usage. Keep the work area clean and free from debris to prevent accidents. **Maintenance and Care:** Regularly clean the decking surface to remove dirt, debris, and any potential stains. Inspect the decking structure periodically for signs of wear or damage, and repair as needed to maintain its integrity. Consider applying a protective sealant or coating to extend the lifespan of the decking and enhance its appearance.

## CONTACT US TODAY

Phone: 02 8000 0085  
0497 637 092

Address: 10 Lancaster Street,  
Ingleburn NSW



Panel color: IPE